

A B C D E F G H

1

2

3

4

5

6

1

2

3

4

5

6

BARCODE LABEL  
X-4130 RATING SEAL

X-4130 SHIELD SHEET-3

X-4130 LOWER CASE  
(URETHANE LEG ASSY品)  
POWER PCB  
(KLM-2679)

X-4130 JACK PANEL  
X-4130 JACK PLATE  
MAIN PCB(KLM-2677)  
X-4130 PCB CHASSIS

EARTH SPRING(K)  
CORTING CLIP  
X-4130 SHIELD SHEET-1  
PANEL PCB(KLM-2680)

LCD PCB(KLM-2678 LED:White)  
SPACER-2  
SPACER-1  
REFLECTION SHEET  
BL PLATE  
DIFFUSION SHEET  
LCD  
EARTH SPRING(K)  
CORTING CLIP

WHEEL ANGLE  
WHEEL SPRING  
WHEEL KNOB

X-4130 SLIDER KNOB  
X-4130 ROTARY KNOB-1  
X-4130 PANEL SHEET-1

X-4130 LCD WINDOW  
X-610 ENCORDER KNOB  
X-4130 PANEL SHEET-2

X-4130 SHIELD SHEET-2  
PANEL PCB  
(KLM-2681)

PIPE  
EARTH SPRING(K)  
HEAD PHONE PCB(KLM-2684)  
RUBBER BOTTON 12  
GND LINE  
KEY PCB(KLM-2665)  
KEY PCB(KLM-2664)

X-4400 JS KNOB  
X-4400 OVAL BUTTON 4-KEY

KEY ASSY 12(M)

PIPE  
X-4130 UPPER CASE  
(KEY GUIDE RUBBER,KB FELT-1 ASSY品)

RUBBER BOTTON 13  
KEY PCB(KLM-2663)

KEY ASSY 13(M)

▲					
▲					
▲					
▲					
REVISAL MARK	REVISAL REASON	REVISAL DATE	REVISED BY	APPROVED	

			DRAWN	CHECKED	APPROVED	MODEL	X-4130(X50)
			T.Shimokawa		Takeda	TITLE	X-4130
			2006.3.31		2006.3.31		ASSEMBLY DRAWING
記号	規格	使用数	KORG KORG INC.		DRAWING No.	KOE-F32149	
	ねじ指示表						